

Instructions

Saturn TAAT



Part No. 95200-01

NOTE: Fits Type 1 or Type 2 valve bodies.



1. Disassembly

- a. Remove OE boost retainer, boost sleeve and plunger assembly, spring guide, pressure regulator spring, the broken orange cushion spring pieces, and pressure regulator valve.
- b. Discard OE broken spring and keep other parts for reuse.

2. Installation & Assembly

- a. Be certain all debris has been removed from the valve bore and valve body.
- b. Reassemble and install valve bore line up using Sonnax cushion spring.