

## Forward Planetary Bearing

### Part No.

**96003-01**

**NOTE:** Roller bearing style.


## Installation Tool

### Part No.

**96003-MTL**

**WARNING:** Required tool kit **96003-MTL** is no longer in production. Check with your distributor for availability.

## Ford 4F50N, AX4S, AX4N, AX0D, AX0DE



### 1. Disassembly

Use a suitable driver to remove old OE bushing (do not try to remove with a chisel).

### 2. Installation & Assembly

- Place Sonnax bearing on installation tool and press into bore until tool stops against planet carrier.
- Verify correct depth and that lube holes are not blocked by bearing.