

Servo Piston & Cover Kit

Part No.
28821-08K

- Cover Non-Anodized
- Pipe Plug
- Hex Head Bolts (3)
- Cover O-Ring
- Cover Gasket
- Piston Seal Rings (2) PTFE
- Piston



Before installing servo, inspect OE servo bore and remove any burrs or sharp edges. Take special notice of the corner at intersection of feed hole and any scratches in bore diameter.

