

Oversized Pressure

Regulator Valve Kit

124740-60K

Part No.

Tool Kit

Part No.

Reamer Reamer Jig

• Guide Pin

F-124740-T

NOTE: Sonnax "F-Tool" kits designed to service a specific bore require the VB-FIX,

a self-aligning valve body reaming fixture.

More information and instructions can be found online at www.sonnax.com.

60

ValveEnd Plug

Instructions

GM 6T70 (Gen. 2), 6T75 (Gen. 2), 6T80 (Gen. 2)



1. Disassembly

- a. Remove OE retaining clip and spring, and set aside for reuse.
- b. Remove and discard OE end plug and pressure regulator valve.

2. Bore Reaming

Ream pressure regulator bore (for reaming instructions/reamer care, please visit www.sonnax.com). Sonnax reaming tool kit **F-124740-TL60** and **VB-FIX** are required for this operation.

NOTE: Clear chips from reamer and bore often to ensure full ream depth in blind bore.

3. Installation & Assembly

- a. Be certain all debris has been removed from valve bore and valve body.
- b. Install Sonnax pressure regulator valve.
- c. Reinstall OE spring.
- d. Install Sonnax end plug.
- e. Reinstall OE retaining clip.

4. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 14 and 18 in-Hg.



©2019 Sonnax Transmission Company, Inc. • A Marmon / Berkshire Hathaway Company

124740-60K-IN 08-09-19