TRANSMISSION PARTS

Instructions

GM 125, 3T40

Accumulator Piston Kit


Part No. 75921-01K

- Piston
- Pin

Also Available


Oversized Accumulator Pins

75921-02K



Oversized Accumulator Pin & Reamer Kit

75921-03K



1. Disassembly

- a. Remove OE piston, spring, and pin from channel casting.
- b. Discard OE piston, seal, and pin.

2. Assembly and Installation

- a. Install Sonnax accumulator pin, piston and a replacement seal (not included).
- b. Install OE spring on top of accumulator piston in channel casting cavity.