Instructions

# Oversized Secondary Pressure Regulator Valve Kit

## Part No. 122740-24K

- Secondary Pressure Regulator Valve
- Boost Valve
- Boost Sleeve
- Spring

## **Tool Kit**



# Part No.

- F-122740-TL24
- Reamer
- Reamer Jig
- Guide Pin

**NOTE:** Sonnax "F-Tool" kits designed to service a specific bore require the VB-FIX, a self-aligning valve body reaming fixture. More information and instructions can be found online at www.sonnax.com.

# 1. Disassembly

- a. Remove OE retainer and save for reuse.
- b. Remove and discard OE boost valve and sleeve assembly.
- c. Remove and discard OE spring and secondary pressure regulator valve.

### 2. Bore Reaming

Ream secondary pressure regulator bore (for reaming instructions/reamer care, please visit www.sonnax.com). Sonnax reaming tool kit **F-122740-TL24** and **VB-FIX** are required for this operation.

#### 3. Installation & Assembly

- a. Be certain all debris has been removed from the valve bore and valve body.
- b. Install Sonnax secondary pressure regulator valve.
- c. Install Sonnax spring.
- d. Install Sonnax boost valve and boost sleeve assembly.
- e. Reinstall OE retaining clip.

#### 4. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in-Hg (**Figures 1 & 2**).

## **Aisin Seiki AS66RC**





